

How to link / bridge 2 PHD10000W2 amplifiers:

- Set master amp phase to 0
- Set slave amp phase to 180
- Set gains equal on both master & slave amplifiers.
- Set the bass boosts and filters equal on both amps

